






SCUBAPRO MK 16 First Stage

Trouble Shooting Guide




Symptom	Correction		Tools Needed
Audible leak from ports or plugs	Tighten ports and plugs	Replace damaged o'rings Seat all o'rings properly	Adjustable wrench
			




High IP (3000 psi supply)	Adjust IP down (counterclockwise)	6 mm hex wrench	Pneumatic adjusting tool
			

Low IP (3000 psi supply)	Adjust IP up (clockwise)	6 mm hex wrench	Pneumatic adjusting tool
			

SCUBAPRO MK 16 First Stage

Trouble Shooting Guide

Symptom	Correction		Tools Needed	
Audible leak from end cap	Inspect diaphragm and retaining washer. Replace if needed.	Tighten end cap while holding unit with field handle		
				

Initial IP creep on gauge	New seat: Cycle regulator 20 – 25 times	Pneumatic adjustment tool
		

Continuous IP creep on gauge	Replace seat or o'rings	Replace body	Various
