LIFETIME GUARANTEE TO THE FIRST OWNER

Your OCTO+ is guaranteed against any defects in materials and workmanship. This guarantee does not cover damages from accident, abuse, neglect, alterations, improper usage or failure to follow reasonable care and maintenance. To validate your warranty you must fill out and return your warranty

OCTO+

MKII

Owners Manual

B. Surface Use

When diving with your OCTO+, you will normally inflate your BC with the power inflate button while resting on the surface. Should you need to orally inflate your BC, get a full breath, then blow into the oral inflation port while depressing the larger control button and releasing the button before removing your lips from the inflation port. Continue adding breaths until the BC has adequate buoyancy.

C. Descending and Ascending

To start your descent or slow your ascent you will need to hold the OCTO+ over your head and gen-



stage, position yourselves with your right shoulders across from one another and grasp each others' RIGHT shoulder strap leaving your LEFT hands free to control your BC. Once you have established control, start your ascent being sure to vent your BCs to control your rate of ascent.

Since the "regulator" and "inflator" functions of the OCTO+ are separate, you may still vent your OCTO+ by pressing on the larger control button or add air to your BC by pressing on the smaller inflate button while breathing on the OCTO+.

Receiving air as the diver who is out of air

It is imperative that you determine what type of equipment your buddy is using and the technique to be used in an out of air emergency PRIOR TO EACH DIVE! Should your buddy also be using the