






# **SCUBAPRO Balanced Power Inflator** **Trouble Shooting Guide**

Symptom	Correction	Tools Needed
Continuous leak from inflator (continuous BC inflation)	Replace inflator seat or stem o-rings	High IP – See first stage trouble shooting guide
		
External leaks from exhaust or inflator buttons	Replace and/or lubricate inflator or exhaust stem o-ring. Replace exhaust seat	Various
